



8' ground rod, clamp and #6 bare copper ground wire  
 (Supplied and installed by consumer)  
 Grounding conductor shall be connected from the ground lug in meter  
 base and C T Cabinet to the ground rod(s)  
 Cooperative requires the meter base and C T Cabinet to be grounded

COOPERATIVE TO PROVIDE CT CABINET, METER BASE AND METER  
 CONSUMER TO PROVIDE SERVICE POLE STRUCTURE PLUS ALL  
 MATERIALS BEYOND THE CT CABINET COOPERATIVE TO CONNECT  
 TO CONSUMER'S CABLE IN CT CABINET

**SERVICE POLE GUIDE WITH CT CABINET**  
 SINGLE PHASE 600-800 AMP



CENTRAL VIRGINIA  
 ELECTRIC COOPERATIVE

11/07/2012